




1.- Do not eat, drink or smoke for 30 min before the sampling.



2.- Place swab tip between your lower gum and cheek and gently rub 10 times back and forth.




3.- Repeat on the other side.



4.- Insert the swab tip inside the provided tube and bend the handle to cut it at the breakpoint.



5.- Close the tube tightly.



6.- Mix by inverting.

7. Place the tube in the sample bag and then in the mailer. Drop it at any mailbox.